


ASSEMBLY INSTRUCTIONS



Description : QUILT RACK
Item No. : 52390

BEFORE ASSEMBLY









Thank you for purchasing this quality product. This product has been designed for easy assembly and constructed for durability. All parts were checked prior to packaging to insure quality. Prior to beginning assembly, however, make sure all parts and hardware are included and free of obvious defect. If a part is missing or defective, please contact the store where purchased. If hardware is missing, or you need help with assembly, please call toll free 888-944-8396.

IMPORTANT NOTE:

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Remove all wrapping material, including staples & packing straps before you start to assemble.
- DO NOT tighten all screws and bolts until completely assembled.
- Keep all hardware parts out of reach of children.





PART LIST

When unpacking, please be careful not to discard any parts with the packaging. Before continuing, please make sure you have the following parts:

NO	Description	Qty	Sketch	NO	Description	Qty	Sketch
A	Leg	2		B	Brace	1	
C	Long rod	2		D	Short rod	1	
E	Top knob	2		F	Bottom knob	2	
G	Arm(L-R)	4		H	Foot	4	


HARDWARE LIST

When unpacking, please be careful not to discard any parts with the packaging. Before continuing, please make sure you have all of the following hardware:

NO	Description	Qty	Sketch	NO	Description	Qty	Sketch
1	Long bolt (M6x65mm)	4		2	Short bolt (M6x35mm)	4	
3	Wood Plug (φ14.5mm)	8		4	Allen key (M4x30mmx120mm)	1	


STEP 1

Insert arms (G) and feet (H) into legs (A). Then attach knobs (E) and (F) to legs (A) as shown below.



STEP 2

Attach brace (B) and short rod (D) to legs with screws (1) as shown below. Tighten with Allen key (4). Attach long rods (C) to legs with screws (2) as shown below. Tighten with Allen key (4).



STEP 3

Insert wood plugs (3) over screws to cover them.

