

BEFORE ASSEMBLY

Thank you for purchasing this quality product. This product has been designed for easy assembly and constructed for durability. All parts were checked prior to packaging to insure quality. Prior to beginning assembly, however, make sure all parts and hardware are included and free of obvious defect. If a part is missing or defective, please contact the store where purchased. If hardware is missing, or you need help with assembly, please call toll free 888-944-8396.

IMPORTANT NOTE:

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Remove all wrapping material, including staples & packing straps before you start to assemble.
- DO NOT tighten all screws and bolts until completely assembled.
- Keep all hardware parts out of reach of children.

WARNING:

Long exposure to rubber or soft plastic may cause a chemical reaction and damage the finish of your product. Protect the surface of the product with cloth if you are using any product with rubber feet or base.



PART LIST

When unpacking, please be careful not to discard any parts with the packaging. Before continuing, please make sure you have the following parts:

NO	Description	Qty	Sketch	NO	Description	Qty	Sketch			
A	Тор	1		В	Leg (L-R)	4				
с	Shelf	2								
ITEM NO.: WC-4824 Printed in Vietnam REVISED NOV 14, 2014										
- 2 -										


HARDWARE LIST

When unpacking, please be careful not to discard any parts with the packaging. Before continuing, please make sure you have all of the following hardware:

NO	Description	Qty	Sketch	NO	Description	Qty	Sketch
1	Bolt (M6x50mm)	8	<u>()</u>	6	Pan head screw (M4x30mm)	2	Januananan
2	Spring washer (¢6.5x11mm)	8	\bigcirc	7	Long screw (M4x25mm)	3	@mmmmm>
3	Flat washer (φ6.5x19mm)	8	0	8	Wood knob (ф32xH32mm)	2	
4	Cup holder	3		9	Shelf support pin	8	
5	Allen key (4x80mm)	1		10	Short screw (M3x15mm)	8	(Cummo


STEP 1

Attach cup holders (4) to top (A) with screws (7) as shown below. Tighten with a screwdriver.




STEP 2

Attach legs (B) to the top (A) with bolts (1),and washers (2), (3) as shown bellow. Tighten with Allen key (5).




STEP 3

Insert pins (9) into legs (B). Place the shelves (C) on the pins (9) and attach with screws (10) as shown below. Tighten with a screwdriver.



STEP 4

Attach knob (8) to front of drawers with Pan head screw (6) as shown below. Tighten with a screwdriver.



Printed in Vietnam