


# ASSEMBLY INSTRUCTIONS

---



---

Description : BUFFET W/2 DRAWERS/3 DOORS  
Item No. : B-3

## BEFORE ASSEMBLY

Thank you for purchasing this quality product. This product has been designed for easy assembly and constructed for durability. All parts were checked prior to packaging to insure quality. Prior to beginning assembly, however, make sure all parts and hardware are included and free of obvious defect. If a part is missing or defective, please contact the store where purchased. If hardware is missing, or you need help with assembly, please call toll free 888-944-8396.

### IMPORTANT NOTE:

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Remove all wrapping material, including staples & packing straps before you start to assemble.
- DO NOT tighten all screws and bolts until completely assembled.
- Keep all hardware parts out of reach of children.

### WARNING:

Long exposure to rubber or soft plastic may cause a chemical reaction and damage the finish of your product. Protect the surface of the product with cloth if you are using any product with rubber feet or base.



### ASSEMBLY TOOLS REQUIRED

NOT INCLUDED



## PART LIST

When unpacking, please be careful not to discard any parts with the packaging. Before continuing, please make sure you have the following parts:







NO	Description	Qty	Sketch
A	BUFFET WITH 2 DRAWERS 3 DOORS	1	
B	SHELF PANEL	3	

ITEM NO.: B-3  
REVISED JAN 24, 2015

Printed in Vietnam


## HARDWARE LIST

When unpacking, please be careful not to discard any parts with the packaging. Before continuing, please make sure you have all of the following hardware:

NO	Description	Qty	Sketch	NO	Description	Qty	Sketch
1	Knob	5		4	Short screw (M3x15mm)	14	
2	Pan head screw (M4x30mm)	5		5	Long screw (M4x30mm)	1	
3	Bracket	12		6	Steel band	1	
				7	Warning label	5	<div> <b>WARNING!</b>            THIS ITEM IS PRONE TO TIPPING.            USE ANTI-TIPPING HARDWARE (PROVIDED) TO SECURE TO THE WALL.            DO NOT ALLOW CHILDREN TO CLIMB ON FURNITURE.            PLACE HEAVIEST OBJECTS IN LOWER DRAWERS.            DO NOT OPEN MORE THAN ONE DRAWER ON THE UNIT AT THE SAME TIME.            DO NOT PLACE TV ON THE TOP OF THE DRESSER OR DRAWER CHEST.         </div>

## STEP 1


Attach brackets (3) to the unit (A). Insert the shelves (B), and attach with screws (4). Tighten with a screwdriver



## STEP 2

Attach Knobs (1) to front of drawers and doors with screws (2). Tighten with a screwdriver (not included).

Attach the Steel band (6) to the unit with screws (4). Attach the Steel band to the wall with screw (5) as shown below (to secure the product and prevent tipping).



## STEP 3

Stick the Warning labels (7) inside all drawers and doors before use.

