


ASSEMBLY INSTRUCTIONS



Description	: HUTCH W/3 DOORS 54X12X36
Item No.	: H-3

BEFORE ASSEMBLY

Thank you for purchasing this quality product. This product has been designed for easy assembly and constructed for durability. All parts were checked prior to packaging to insure quality. Prior to beginning assembly, however, make sure all parts and hardware are included and free of obvious defect. If a part is missing or defective, please contact the store where purchased. If hardware is missing, or you need help with assembly, please call toll free 888-944-8396.

IMPORTANT NOTE:

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Remove all wrapping material, including staples & packing straps before you start to assemble.
- DO NOT tighten all screws and bolts until completely assembled.
- Keep all hardware parts out of reach of children.

WARNING:















Long exposure to rubber or soft plastic may cause a chemical reaction and damage the finish of your product. Protect the surface of the product with cloth if you are using any product with rubber feet or base.

ASSEMBLY TOOLS REQUIRED NOT INCLUDED



PART LIST

When unpacking, please be careful not to discard any parts with the packaging. Before continuing, please make sure you have the following parts:
















NO	Description	Qty	Sketch	NO	Description	Qty	Sketch
A	Crown	1		H	Top back center panel	1	
B	Front frame with doors	1		I	Top back side panel	2	
C	Base frame	1		J	Bottom back panel	1	
D	Back rail	1		K	Vertical rail	2	
E	Side panel (L&R)	2		L	Glass (Shelf)	2	
F	Adjustable frame	1		M	Glass (Door)	3	
G	Bottom shelf	1		N	Light (light-connector)	1	

ITEM NO.: H-3
REVISED AUG 19, 2016

Printed in Vietnam


HARDWARE LIST

When unpacking, please be careful not to discard any parts with the packaging. Before continuing, please make sure you have all of the following hardware:

NO	Description	Qty	Sketch	NO	Description	Qty	Sketch
1	Long bolt (M6 x 45mm)	4		9	Short pan head screw (M5 x 20mm)	6	
2	Medium bolt (M6 x 30mm)	4		10	L-Bracket	3	
3	Lock Washer (φ6.5 x 11mm)	4		11	Bracket	6	
4	Flat Washer (φ6.5 x 13mm)	4		12	Metal plate (1.8 x 40 x 60mm)	2	
5	Long screw (M4 x 40mm)	2		13	Steel band	2	
6	Medium screw (M4 x 30mm)	18		14	Knob	3	
7	Short screw (M3.5 x 15mm)	26		15	Allen key (M4 x 30mm x 120mm)	1	
8	Long pan head screw (M4 x 30mm)	3					


STEP 1

Attach light (N) to crown (A) with short screws (7) as shown below. Tighten with a screwdriver.



STEP 2

Attach glass sections (M) to back of front frame with doors (B) and lock it, as shown below.
Attach knobs (14) to doors with long pan head screws (8) as shown below. Tighten with a screwdriver.




STEP 3

Attach vertical rails (K) to bottom shelf (G) with bolts (1) as shown below. Tighten with Allen key (15). Then slide top back center panel (H) into the grooves.

Attach back rail (D) to vertical rails (K) with bolts (1) as shown below. Tighten with Allen key (15).


Slide back side panels (I) into the grooves as shown below.



STEP 4


Attach side panels (E) to back rail (D) with short pan head screws (9) as shown below. Tighten with a screwdriver.

Attach side panels (E) to bottom shelf (G) with bolts (2), and washers (3) and (4) as shown below. Tighten with Allen key (15).




STEP 5

Attach front frame with doors (B) to the unit with short pan head screws (9) as shown below. Tighten with a screwdriver.




STEP 6

Attach L-brackets (10) with short screws (7) as shown below. Tighten with a screwdriver.




STEP 7

Slide bottom back panel (J) into the grooves as shown below.



STEP 8


Attach base frame (C) to side panels (E) with screws (6) as shown below. Tighten with a screwdriver.



STEP 9


Insert brackets (11) into the unit. Place the frame (F) on the brackets and attach with screws (7) as shown below. Tighten with a screwdriver.

Place glass shelves (L) on the frame (F) as shown below.



STEP 10

Attach crown (A) to the unit with screws (6) as shown below. Tighten with a screwdriver.



STEP 11

Attach connector (N) to the unit with long screws (5) as shown below. Tighten with a screwdriver. Attach metal plates (12) to the unit with short screws (7) and attach metal plates (12) to buffet or server (to secure the product and prevent tipping). Tighten with a screwdriver.

Attach steel bands (13) to the unit with short screws (7) and attach steel bands (13) to the wall with medium screws (6) as shown below (to secure the product and prevent tipping). Tighten with a screwdriver.

